## **APS Processing**



To start the APS processing, press the Go button next to the APS estimation label in the Multi-Image InSAR processing group.



The APS Processing window opens. There are quite a lot of options to choose from. We are going to address the standard parameters step-by-step. In the beginning, we need to select the sparse points used for the processing. For this, we have to select a parameter used for the sparse point selection. There are quite a lot of parameters available. A good standard choice is the Amplitude Stability Index 1 – Sigma/Mu. Therefore, we are selecting Amp. Stab. Index 1 – Sigma/Mu in the Parameters box of the Sparse Points Selection group. As threshold, we enter 0.8 in the Thresh. text box. Then we press Go in the Sparse Points Selection group. Afterwards you can plot the selected points via the Plot button in the Sparse Points Selection group.



Now, we connect the graph using the Go button in the Graph Creation group. With the standard parameters a Delauny triangulation is used, which should be good in most cases. Afterwards you can plot the selected points via the Plot button in the Graph Creation group.



First, we chose some standard parameters for the processing. We estimate the linear trend between - 100 to 100 mm/year and the height between -100 to +100m around the SRTM height. We therefore use the Ext. DEM for the height estimation.

APS Processing - D:\Projects\LasVegasDescending\							
– Images Selectio	Images Selection						
Bn 1500	Bn 1500 DC 0.5 Images Nr: 20 Without APS: 20 Process all APS Mixed graph Conn. Nr. 20						
- Sparse Points :	Selection						
Paran	Parameter Thresh. DS DL						
Amp. Stab. Inc	dex 1-Si ♥	.8	30 0 PSC	Nr: 31613 Go Plot Save Load			
– Graph Creation							
Min Nr Min	IR MaxR	R Step					
Flowere	ed Tree	0	Go Plot	Connections Nr: 94780 Save Load			
- Processing Par	ameters			- Connections processing			
1100000	Estimate Rea	d Neglect	Parameters Range				
Linear			400 400	Go Clear Diffs Save As Load			
Trend			-100 100	Connections coherence Non-Linear Weighing			
Height	• •	0	-100 100	Hist         Plot Graph         m         p         M         Plot			
Azimuth	0 0	۲	-1 1	Reference Point			
PUS.				Go Plot Save As Load 250			
Phase Shift	0 0	۲	-pi pi				
Seasonal				Estimated Parameters Go			
Trend	0 0	۲	4 .4	Plot         1         1         0         Save         Plot			
Ext. DEM	Smart	0	N min Gen 50	- APS options			
Scattering 1 Polynomial order 0 LP. O LR. O TriLR. Stratif. R 150 DSF 25							
Matr Coher )	Metr. Coher Min						
15     15     Weights        • None        Coher        Amps        Go        Plot        Test        OK							
				SARPROZ © 2009, the SAR PROcessor by periZ			

Afterwards, we press Go in the Connections processing group. This may take a while. After finishing, we check the Histogram and the connections Graph in the Connections coherence group by pressing Hist and Plot Graph.



They look good. We keep the standard parameters for the Non-Linear Weighing and press Plot in the Non-Linear Weighing group.



Looks OK, so we can continue. We calculate the reference point by pressing Go in the Reference Point group. Then we estimate the parameters by pressing Plot in the Estimated Parameters group.



No the difficult part starts. We have to analyze the results and decide if they are OK and we continue, or if we have to adjust some parameters. This is a matter of experience and also requires a willingness to play with the parameters to see their effect. Well, in the results above, the heights look OK, at least we can see some of the high buildings are estimated correctly. However, the velocity is quite noisy and we are not satisfied.

One parameter to adjust easily, without needing a long reprocessing, is the non-linear weighing. We are getting a bit more aggressive and going for 0.7, 0.85, 1



Again we recalculate the reference point and plot the estimated parameters.



Well, this looks already much better. The histogram of the integrated residual heights is shifted to the left, which might be because the selected reference point is on a building and not on the ground. We can select another reference point by pressing Load in the Reference Point group.

2	Select File to Open		×
Look in:	MATLAB 🔹	+ 🗈 💣 💷 -	
Recent places	Name Atmo. Grafo. Matrinc26.06.2013.13.03.32 Atmo. Grafo26.06.2013.13.03.31 Atmo. Pesi26.06.2013.13.06.35 Atmo. Pesi26.06.2013.13.06.35 AutoConnex AutoConnex	Date modified 6/26/2013 1:03 PM 6/26/2013 1:03 PM 6/26/2013 1:06 PM 6/26/2013 4:21 PM 6/26/2013 8:47 AM	Type         ^           MATU         MATU           MATU         MATU
Libraries () Computer	AutoRef2 AutoRef3 AutoRef4 AutoRef5 ConceParam	6/28/2013 8:47 AM 6/28/2013 8:47 AM 6/28/2013 8:47 AM 6/28/2013 8:47 AM 6/28/2013 8:47 AM	
Network	DefParam  DefMExtension  GCP  III	6/25/2013 7:38 AM 6/26/2013 11:17 AM 6/26/2013 10:06 AM	
	File game: Files of type: MAT-files (* mat)	• •	Open Cancel

SARProZ is automatically creating five points called AutoRef1 to AutoRef5. We select AutoRef3 and plot the estimated parameters.



The height shift has gone. The results look OK and we could continue processing. However, we see that in our height estimation, the value of -100 to +100 might not be an optimal choice, because there are quite high buildings in the Las Vegas scene.

We are therefore changing our processing parameters. We are trying to estimate the height from -50 to 150m. We also saw in our first results that the velocity might be not so high. Therefore, we reduce the estimation range from -60 to 60 mm.

		A	PS Processing - D:\Pr	ojects\LasVegasDescending\			
- Images Select	ion						
Bn 1500	DC 0.5	● mono-se	nsor Images Nr: 2 Conn. Nr. 2	Without APS: 20      Process all APS      Mixed graph			
-Sparse Points Para Amp. Stab. In	Selection meter idex 1-Si Y	Thresh.	DS DL 30 0 PSC	Nr: 31613 Go Plot Save Load			
- Graph Creatio Min Nr Mi 0 I Flower	Min Nr         Max R         R Step           0         0         0         0         Generations Nr:         94780         Save         Load           Flowered Tree         Flowered Tree         Save         Load         Save         Save         Save         Save						
Processing Pa	rameters Estimate Rea	d Neglect	Parameters Range	Connections processing Go Clear Diffs Save As Load			
Linear Trend	• 0	0	-60 60	Connections coherence Non-Linear Weighing			
Height	•	0	-50 150	Hist         Plot Graph         m         p         M         Plot           0.7         0.85         1         Plot			
Azimuth Pos.	0 0	•	-1 1	Reference Point			
Phase Shift	0 0	۲	-pi pi	Go Prot Save As Load 250			
Seasonal Trend	0 0	•	-4 .4	R         r0         ds         Flatten         Optional           Plot         1         1         0         Save         Plot			
• Ext. DEM	Ext. DEM Smart 0 N min Gen 50     APS options						
Scattering 1 Polynomial 1 Recover   I Difference of the second se							
Matr. Coher.	Win 5 Weight	s 🖲 None	○ Coher ○ Amps	APS Estimate Go Plot Test OK			
				SARPROZ @ 2009, the SAR PROcessor by periZ			

Again we press Go in the Connections processing group to start the process and see the coherence by pressing Hist and Plot Graph in the Connections coherence group.



We are still using 0.7, 0.85, 1 for the non-linear weighing.



We again select a reference point by pressing Go in the Reference Point group.



Well, this time we are satisfied with the results. However, we could (and probably should) continue to search for optimal parameters in the above described way.

Finally, we go for the APS processing selecting the right option in APS options. I.P. stands for inverse parameters and is a rather stable estimator for the APS. I.R. stands for inverse residuals and can offer better results in good cases, which means cases with coherent and a large amount of data. Tri. I.R. is using triangulation for the inverse residuals. Stratif. stands for stratified and can be used when different atmospheres in different heights are to be expected. Be aware, that to use this successfully, a larger amount of images is typically necessary.

<b>4</b>		A	PS Processing - D:\Pro	pjects\LasVegasDescending\			
- Images Selecti	on						
Bn 1500	DC 0.5	◉ mono-se	ensor Images Nr: 20 Conn. Nr. 20	0 Without APS: 20			
- Sparse Points	Sparse Points Selection						
Para	neter	Thresh.	DS DL				
Amp. Stab. In	dex 1-Si ♥	.8	30 0 PSC	Nr: 31613 Go Plot Save Load			
Graph Creation	۱ <u> </u>						
Min Nr Mi 0 0 Flower	Min Nr         Min XR         R         Rstep           0						
Processing Pa	Processing Parameters     Connections processing						
	Estimate Rea	d Neglect	Parameters Range	Go Clear Diffs Save As Load			
Linear Trend	• 0	0	-60 60				
Height	• C	0	-50 150	Connections coherence Non-Linear Weigning m p M Plot Graph 0.7 0.85 1 Plot			
Azimuth Pos.	0 0	۲	-1 1	Reference Point			
Phase Shift	0 0	۲	-pi pi	Go Plot Save As Load 250			
Seasonal Trend	0 0	۲	4 .4	Plot 1 1 10 Save Plot			
Ext. DEM	Ext. DEM Smart 0 N min Gen 50     APS options						
Scattering centers	1	Polynomial order	1 Recover	O LP.			
Matr. Coher.	Win 5 Weight	s 🖲 None	O Coher O Amps	APS Estimate Go Plot Test OK			
				SARPROZ © 2009, the SAR PROcessor by periZ			

In our example, we select I.R. because we have a very stable and coherent dataset and we are optimistic. The APS is estimated by pressing Go in the APS Estimate group. Afterwards we can plot through the estimated APS by pressing the Plot button in the APS Estimate group.



By pressing the Test button in the APS Estimate group, we can get an estimation of the APS estimation quality.



Finally, we can close the APS estimation by pressing the OK button.